

For iPhone users the app can be downloaded on the apple store (search **sauna remote controller**)



For Android users you will need to download from this **QR code link below**

1.Scan the QR code below with a browser and download it



2.After installing the APP, click to enter the main interface of the APP, as shown in the following figure. The user does not have a device when entering for the first time and needs to add it. Click on the device to enter device addition.

Turn on Bluetooth and click on 'Find Device' to enter the Bluetooth network. Upon successful user operation, YFX will be displayed. Clicking YFX will show the required WIFI device to be connected. Manually enter the WIFI name, WIFI password, and device name (custom), click bind, and after successful binding, return to the main interface. When the newly added device icon lights up, it indicates that AWS has been connected, and remote control can be performed at this time




SSID = WIFI DEVICE NAME

PASSWORD = WIFI PASSWORD

DEVICE NAME = WHAT YOU WOULD LIKE TO CALL YOUR SAUNA

3.Wait until the device goes online, at which point the network adapter will display a flashing blue light. After the device goes online, it will light up and click on the device name to enter the device.



4.QR codes are used for multi person binding. If there is a need for multiple people to bind the same device, clicking on the share device will generate a QR code. The user who needs to bind can scan the QR code to complete the binding.



Remark:

1. Long press the music button for 5 seconds to enter WIFI mode
2. Both Bluetooth and location on the phone need to be turned on

Indicator Light Description

The network adapter has a red light when it is not connected to the internet by default, a green light when it successfully connects to WIFI, a flashing blue light when it successfully connects to AWS, and a constant blue light when the device is turned off for a period of time. The blue light flashes when the device is turned on.



Note:

If the control panel inside your sauna will not go above **65 °C**, you can increase the maximum temperature setting to **70 °C** by following these steps:

- Turn on your sauna using the **control panel**.
Press and hold the **“+” and “-” time buttons simultaneously for 10 seconds**.
You will hear a **beep**, indicating that the maximum temperature has been successfully raised to **70 °C**.